

Tstat8 | Bacnet Thermostat 8

Description

This full-featured thermostat is designed for cooling and heating systems in residential and commercial buildings. The thermostat can be configured for use with air handlers, fan coils, VAV, modulating valves and practically any HVAC application. All models support bacnet and modbus protocol which allows easy integration with the big name control systems like Niagara, Siemens, Honeywell, Johnson Controls, Delta, Reliable and Kreuter to name a few.

There are five relays and two analog outputs as well as 8 universal inputs. These i/o can be configured using the free software. There are more than 300 settings with many options for each of the settings so its possible to configure these devices for most any application. Once the unit is configured, save the config file for copying to other controllers and backing up project settings.


Options are available for humidity / enthalpy.




Highlights

- Bacnet MSTP and Modbus RTU protocols over RS485.
- Baudrates : 9600, 19.2k, 38.4k, 57.6k, 76.8k and 115.2kbaud.
- Well documented register list for easy integration with other systems.
- 8 universal inputs for external temperature sensors, contacts, etc.
- 5 relay outputs, each rated at 24vac, 2 amps.
- 2 analog outputs, 0-10V @ 100ma.
- Color LCD display with scroll bar.
- Easily configure the thermostat for practically any application.
- Clock with infinite life supercap battery backup.
- Uses 32 bit Arm CPU with 12 bit analog readings, support voltage up to 220V..

T3000 software




Typical Application




Specifications

• Tstat8	5 relays x 10amps @220VAC, 8 analog inputs, 2 analog outputs 10V@100mA
• Operating temperature	-30~70°C (-22~158°F)
• Supply voltage	12~24VAC/DC ±20%, 50-60Hz
• Power consumption	100mA at 12VDC
• Relay contacts	rating 10A @ 30VDC, 12A @ 250VAC UL File No.: E169380
• Baudrate	9600, 19200, 38400, 57600, 115200
• Ambient humidity	10-90 %Rh
• Operating Environment	0 ~ 99% humidity non condensing
• Plastic Housing	Flammability rating UL 94 V0 file E56070
• Enclosure rating	Ip31
• Protocols	Bacnet MSTP and Modbus RTU
• Temperature sensor	10K thermistor ±0.5°C



Size

Wiring Diagram



Part Number Scheme


Tstat8 – OCC – W/B

Code	Description
Tstat8	Thermostat

Code	Description
	Basic model temperature and clock
H	Humidity
OCC	Occupancy sensor
220	220V
ZIG	Zigbee


Code	Description
W	White color
B	Black color

Highlights



Advanced Menu Item Details




They have several advanced menu items which can be adjusted in the field to suit the application and tune the operation of the thermostat. Generally speaking, all the parameters are set up at the factory on an order-by-order basis and will give satisfactory results out of the box.



- Last menu item
- Increase value
- Next menu item
- Decrease value

LCD Screen Display




1. When you press ◀ or ▶, it will increase or decrease the set point value. The value will flash two times, then it will confirm the setting automatically.



2. In the normal mode, press both ◀ and ▶ at the same time. Hold for several seconds, it will switch to the menu mode. Press ◀ or ▶ to scroll through the menu options such as 'Add', 'CAL', 'bAU', 'UNITS' and many others. To change the values at a particular menu, press ▲ or ▼, the chosen value will be stored automatically.

To change the unit's address, scroll through the menu until you reach 'Add'. Press ▲ or ▼ to increase or decrease the unit's address from 1 to 254.

To change the baudrate, locate 'bAU' within the menu and use ▲ and ▼ to choose 19200 or 9600.




Custom Enclosures





Black

T3000 operation


1. Connect Tstat8 to PC by RS485, start T3000 software



2. Click the button  to scan, the following view will appear and close it as the picture indicates. When discussing Tstat8, close the view.




T3000 operation

3. Click Tstat8 log, then click "input" , the T3000 will show all the information of it. To change name or choices, click as below.

Click to show input information

Press range to different choices

Click to change the name



The screenshot shows the T3000 Building Automation System interface. On the left is a tree view of the system components, including a 'Tstst8 log' folder containing a 'TSTAT8' device. The main window displays a table of inputs:


NUM	Full Label	Auto/Manual	Value	Units	Range	Calibration	Filter	Function
1	Input1	Auto	-100.0	°C	10K Thermistor Type2	Adjust...	0	Normal
2	Input2	Auto	-100.0	°C	10K Thermistor Type Adjust...		0	Normal
3	Input3	Auto	-100.0	°C	10K Thermistor Type Adjust...		0	Normal
4	Input4	Auto						
5	Input5	Auto						
6	Input6	Auto						
7	Input7	Auto						
8	Input8	Auto						
9	Internal Temp Sensor	Auto						
10	Humidity Sensor	N/A						
11	CO2 Sensor	Auto						
12	Lighting Sensor	N/A						

A 'Select Range Number' dialog box is open, showing options for range selection. The '10K Thermistor Type2' option is selected. The dialog also includes radio buttons for '0-5v' and '0-10v'.

Tstst8 log

4. Click  to do settings, you can see a tab below about setpoint and temperature.

Click to do settings




The screenshot shows the configuration page for a TSTAT8 device. The left sidebar shows the device tree with 'TSTAT8' selected. The main window displays the following configuration details:

- Inputs [AIR-1]:** Sensors and feedback points wired to the controller.
- ID Address:** 254, **Serial Number:** 0
- Name:** TSTAT8
- Firmware Version:** 2.9, **Model:** Tstat8
- Hardware Version:** 0, **PIC:** 0
- Date:** Friday, Dec 23, 2016, **Time:** 01:39:27 PM
- Temperature:** 27.9 °C, **Fan Mode:** Off
- Override Period:** 0, **Time Left:** 0
- PID1 Mode:** COOLING 1, **Output:** 0%
- PID2 Mode:** HEATING 1, **Output:** 100%
- Free Cool Available:** No, **Free Cool Feature:** Normal

On the right, there are setpoint controls for 'DAY' and 'NIGHT' modes. The 'DAY' mode is currently set to 'Occupied' with a setpoint of 25.0 C. The 'NIGHT' mode is set to 'Unoccupied' with a setpoint of 22.0 C. Below these are two vertical temperature gauges showing 'Current Temperature' at 27.9 C.

Input	Name	Value	Output	Name	Value
0	Input1	-100.0	1	Output1	Off
1	Input2	-100.0	2	Output2	Off
2	Input3	-100.0	3	Output3	Off
3	Input4	-100.0	4	Output4	Off
4	Input5	-100.0	5	Output5	Off
5	Input6	-100.0	6	Output6	0.0%
6	Input7	-100.0	7	Output7	0.0%
7	Input8	-100.0			
8	Internal Temp Se	27.9			
9	Humidity Sensor	N/A			
10	CO2 Sensor	-400			
11	Lighting Sensor	8			

T3000 operation

5. Click  to do settings, you can see a tab below about parameter. Click PIDs tables, you can find PIDs set Dialog.

Click to do settings

The screenshot shows the 'Parameter' dialog box for device 'TSTAT8' (ID Address 254). The 'PID' section contains the following data:

Loop	Input select	Input value	Setpt value	Output	Pterm	Item
Loop1	Internal Sensor	28.1°C	24	0%	6.0	5.0
Loop2	Avg Temperatu.	28.1°C	200.0	100%	100.0	1.0
Loop3		28.1	-0.1	48%	25.5	25.5

The 'Special Features' section includes buttons for 'Free cooling', 'Outdoor Reset', and 'Airflow Setting', along with a 'PIDs Table' button highlighted by a red box.

The 'PIDs Set Dialog' window shows the following configuration:

- Fan Mode Name Configuration: Fan Off (Off), Model 1 (On), Fan Aut (Auto)
- #Modes/Speeds: 3, Mode: Off
- Heating Stages: 1, Cooling Stages: 1

PID1 Table:

Description	Control	InterLock	Heat1	Coast	Cool1
1 Output1	PID1	-	Off	Off	Off
2 Output2	PID1	-	Off	Off	Off
3 Output3	PID1	-	Off	Off	Off
4 Output4	PID1	-	Off	Off	Off
5 Output5	PID1	-	Off	Off	Off
6 Output6	PID1	-	Closed	Closed	Closed
7 Output7	PID1	-	Closed	Closed	Closed

PID2 Table:

Description	Control	Interlock	Heat1	Coast	Cool1	Cool2	Cool3
1 Output1	PID1	-					
2 Output2	PID1	-					
3 Output3	PID1	-					
4 Output4	PID1	-					
5 Output5	PID1	-					
6 Output6	PID1	-					
7 Output7	PID1	-					

PID3 Table:

Description	Control	Interlock	Heat3	Heat2	Heat1	Coast	Cool1	Cool2	Cool3
1 Output1	PID1	-							
2 Output2	PID1	-							
3 Output3	PID1	-							
4 Output4	PID1	-							
5 Output5	PID1	-							
6 Output6	PID1	-							
7 Output7	PID1	-							

More Detailed Manual

Description

Code	Description (Range, Default)
Modbus Address	Modbus Device Address (1-254, 254) This is the modbus address of the tstat. It is the address to which the tstat will respond when receiving serial communication.
Temperature Calibrate	<p>Calibration of the Selected Temperature Sensor (0-1000, 500)</p> <p>To calibrate the temperature shown on the tstat display you will need a handheld mercury thermometer or digital thermometer. Hold the meter close to the thermostat and allow it to come to equilibrium. Use the keypad to get into the menu mode until CAL is shown on the display. Now you can adjust the display using the up and down buttons till the temperature shown matches the handheld meter. When you are done, just let the display time out to normal operation, the display will stop flashing and will show the current room temperature. You can repeat this sequence if necessary till the readings on the thermostat and meter agree. The thermostat will store the calibration figures even through extended power outages and should not need to be adjusted for many years. The main point to keep in mind when calibrating is to let everything come to equilibrium. The thermostat should be powered up for 5 minutes prior to any calibration and the thermometer should be left near the thermostat for about the same amount of time.</p> <p>The calibration value is centered around 500 (50.0°). This means that anything above 500 will be added on to the raw temperature and anything below 500 will be subtracted from the raw temperature. Calibration units are in increments of 0.1° (i.e. 500 means 50.0°) and are in the same units (C or F) as the tstat.</p> <p>Some calibration tips:</p> <ul style="list-style-type: none"> * The main error in calibration comes from not waiting long enough for the handheld thermometer to come to equilibrium. * Calibrate using the customer's thermometer, even if it is not an accurate one so that all subsequent measurements are compared to the same benchmark. * The sensor inside the thermostat is a digital chip capable of resolving down to 0.06°C so the weak link in calibrating is usually the procedure used rather than the tstat accuracy. * Make sure the tstat is mounted in a location free of drafts.
Temperature Select	<p>Temperature Sensor Select (0-3, 0)</p> <p>The tstat has an extra input for use with an external temp sensor.</p> <p>tSS = 0: The tstat will use the internal temperature sensor IC for the display and PID calculations</p> <p>tSS = 1: The tstat will use an external thermistor which is shown on the display and used for PID calculations.</p> <p>tSS = 2: The tstat will use an internal thermistor which is shown on the display and used for PID calculations.</p> <p>tSS = 3: The tstat will use an average of internal thermistor and external thermistor which is shown on the display and used for PID calculations.</p>
Temperature Filter	<p>Temperature Sensor Filter (0-10, 5)</p> <p>Filter used for the raw temperature being read by the sensor.</p> <p>This controls the weighted average used when filtering the raw temperature. 0 corresponds to no filter. 10 corresponds to a high level of filtering. Set this to a low value if you want the input to respond quickly, a high value will smooth the readings more but make them respond more slowly.</p>
Baudrate Select	19200, 9600
Short Cycle Delay	<p>Short Cycle Delay (0-20, 0)</p> <p>This parameter adjusts the delay between cycling of the mode of operation. It is the number of minutes after entering coasting mode until the tstat can re-enter the mode it came from. For example, if the tstat is in Cooling1 mode, and then enters Coasting mode, it will take a delay, dSC minutes, until it can re-enter into Cooling1 mode. This value is in increments of 1 min.</p>
ChangeOver Delay	<p>Changeover Delay (0-200, 0)</p> <p>This parameter adjusts the delay between switching from a heating mode of operation to a cooling mode of operation or vice versa. It is the number of minutes after leaving cooling or heating mode before the tstat can enter the opposite mode. This value is in increments of 1 min.</p>

More Detailed Manual

Description

Code	Description (Range, Default)
Proportional Term	<p>Proportional Term (10-255, 20)</p> <p>The proportional term is the 'P' term of the familiar PID control strategy and determines how fast a valve will react to a deviation from setpoint at a particular instant in time. The default value of 2.0° (Cor F) is fine for most applications, where a 2.0° deviation is required to make the valve respond 100%. For example, with the PPr term set to 2.0 (°C) and the cooling setpoint is set to 20°C, the valve will be open 100% by the time the room hits 22°C. A larger PPr term will make the valve lazy since the deviation from setpoint will have to be greater before it opens 100%. A smaller value makes the valve respond more quickly. The factory setting of 2.0° (Cor F) is fine where the thermostat is located out of the direct airflow in an office size room. For a smaller room or if the thermostat is located directly under the air vent, a slower acting valve is required to avoid short cycling, so set the value of PPr to 3.0° or 4.0°. The PPr term acts in cooperation with the PIn term which is described next. The P value is in increments of 0.1° (i.e. 20 means 2.0°) and is in the same units (Cor F) as the tstat.</p>
Integral Term	<p>Integral Term (0-255, 50)</p> <p>The integral term is the 'I' term of the familiar PID control strategy and determines how fast a valve will react to a deviation from setpoint over time. For example with the room slightly above setpoint, the 'P' term may be basically satisfied, but a small deviation still exists. This deviation is summed up or 'Integrated' overtime and the I term will gradually open the valve to make up the final small deviation from setpoint. The default value of 5.0 (%/Degminute) is fine for most applications and will cause the valve to open 5% for one degree (Cor F) of error per minute. For example, when the PIn term set to the default of 5.0 (%/Degminute), the cooling setpoint is set to 20°C, and the room temperature is 21°C, the valve will be open partially due to the "P" term described earlier but the condition continues and we would like the valve to be opening up slowly to make up the final temperature error. If this situation of 1.0°C error continues for one minute, the error accumulates and the I term nudges the valve open an additional 5%. If the previous explanation is not clear, a couple of helpful reminders are as follows: - think of the I term as the opposite of the P term, - a bigger I means fast valve, smaller I means lazy valve". - The default value of 5% will work fine for most applications. - If the valve is short cycling, make the I term lazy (smaller). The I value is in increments of 0.1 %/°min (i.e. 50 means 5.0%/°min) and is in the same units (Cor F) as the tstat.</p>
Operation Sequency	<p>Sequence of Operations (0-2, 1)</p> <p>The Sequence of operation is normally set at the factory and does not need to be adjusted. The thermostat supports field adjustment of the operation to suit different variations of mechanical equipment. Setting this value to a different value will cause the thermostat to stop working properly, so be careful not to adjust this value unless you are familiar with the various sequences.</p> <p>Standard Operation: When SOP is set to 1, the sequence of operations is stored in a table that allows for basically any arbitrary sequence of operation, for example the tstat could be set up to control 5 stages of cooling, 5 stages of heating, or anything in between. Each output is individually assigned to be active in any particular section of the cooling or heating cycle. There are 7 discrete steps, Heat3, Heat2, Heat1, Coasting, Cool1, Cool2 and Cool3. So the table is a 5 outputs x 7 steps spreadsheet arrangement and you fill in the blanks to suit the application. The settings can be stored in an external text file that is easily read and modified in a text editor. The "TstatFactory" software utility on our website (http://www.temcocontrols.com/ftp/tstat5softw are.zip) allows you to send your favorite sequence of operation table to a new tstat speeding up the configuration process.</p> <p>Transducer Mode: Setting SOP to 2, puts the Tstat into transducer mode. In this mode, the cooling analog output corresponds directly to the room temperature in degrees C (i.e. at 25°C, the output would be 2.5V). The heating analog output corresponds directly to the setpoint in degrees C. And relay1 corresponds to the occupied/unoccupied mode (occupied= relay1 ON, unoccupied= relay1 OFF).</p> <p>Test Mode: A special sequence of operations is embedded in the tstat that assists in commissioning of the installation and testing of the tstats. When SOP is set to '0' this is the testing sequence and the unit will cycle the relay outputs on and off in a slow rotation. The analog outputs are also cycled in a slow ramp, the cooling goes from 0-10V while the heating goes in reverse from 10 to 0V. The duty cycle of this rotation is approximately 20 seconds, be sure the mechanical system is able to handle this sort of cycling before using this feature.</p>
HeatCool Config	<p>Heating Cooling Mode Configuration (0-5, 0)</p> <p>This item configures the method by which the tstat determines the heating or cooling mode.</p> <p>HC = 0: mode is controlled automatically by the PID. PID > 52 is heating mode, PID < 48 is cooling mode.</p> <p>HC = 1: mode is controlled by the keypad or serial communication. This is for keypad configurations in which the user or serial com can manually set heating or cooling.</p> <p>HC = 2: mode is controlled by the active high digital input. High is heating, low is cooling.</p> <p>HC = 3: mode is controlled by the active low digital input. High is cooling, low is heating.</p> <p>HC = 4: mode is controlled by difference in temperature of setpoint and analog in 1 sensor. If the temperature of the sensor is greater than the setpoint, the tstat will be in cooling mode, and if the temperature of the sensor is less than the setpoint, the tstat will be in heating mode. This is primarily used for 2-pipe systems.</p> <p>HC = 5: same as mode 4, but using the analog in 2 sensor instead of analog 1.</p>

More Detailed Manual

Description

Code	Description (Range, Default)
Heating Deadband Cooling Deadband	<p>Heating & Cooling Deadbands (1-200, 10)</p> <p>If there is one setpoint, the heating setpoint follows the cooling setpoint and is calculated by: Heating Setpoint = Setpoint - Heating Deadband. Cooling Setpoint = Setpoint + Cooling Deadband</p> <p>If there are two setpoints, heating and cooling are separately adjusted. The setpoints are recalculated as follows: Heating Setpoint = Max(Cooling Setpoint + Cooling Deadband, Heating Setpoint) Cooling Setpoint = Min(Cooling Setpoint, Heating Setpoint - Cooling Deadband)</p> <p>The min value for Cdb is 1.0° (Cor F) to ensure that simultaneous heating and cooling is never allowed. The maximum value is arbitrarily set to 20.0°. The deadband values are in increments of 0.1° (i.e. 20 means 2.0°) and are in the same units (Cor F) as the tstat.</p>
Degree C/F	<p>Degrees C/Degrees F (0-1, -)</p> <p>The display can be switched to show Degrees Cor Degrees F. 0 = C, 1 = F.</p>
FanSpeed Select	<p>Number of Fan Speeds to show on the display (0-3, 3)</p> <p>The number of fan speeds allowed. Fan = 3, user will see "Off,-1-, -2-, -3-, Aut" Fan = 2, user will see "Off,-1-, -2-, Aut" Fan = 1, user will see "Off,-1-, Aut", Fan = 0, user will see "Off,On"</p>
NightHeat Deadband	<p>Night Heating Deadband (0-35, 10) for deg C, (0-95, 10) for deg F</p>
NightCool Deadband	<p>Night Cooling Deadband (0-99, 10) for deg C and F</p> <p>When the tstat is in unoccupied mode, and APP is set to 0, the heating setpoint is adjusted downwards by the amount of the nHd. The cooling setpoint is adjusted upwards by the amount of nCd. The night deadband values are in increments of 1° (i.e. 10 means 10°) and are in the same units (Cor F) as the tstat.</p> <p>Note: The night heating setpoint is prevented through an internal software interlock from being set below 5°C, regardless of the user heating setpoint and the value stored in NHS.</p>
NightHeat Setpoint NightCool Setpoint	<p>Set night heating setpoint and night cooling setpoint, could be degree C or degree F</p>
Application Mode	<p>Application (0-1, 0)</p> <p>0 - OFFICE applications mode The night time setpoints are specified value Night Heating Setpoint = nHS value. Night Cooling Setpoint = nCS value.</p> <p>1 - HOTEL or RESIDENTIAL applications mode The night time setpoints are specified deadband in relation with the day time setpoints Night Heating Setpoint = Cooling Setpoint - nHd value. Night Cooling Setpoint = Cooling Setpoint + nCd value.</p>
PowerUp Setpoint	<p>Power on setpoint (0-255, 20) for deg C, (0-255, 68) for deg F</p> <p>Certain applications require the thermostat to power up with a known setpoint that is stored through a power outage. This feature is useful in some of the transducer modes where the central DDC controller can cycle the power to the thermostats to reset the room setpoints to a known value everyday. The power on setpoint value is in increments of 1° (i.e. 20 means 20°) and is in the same units (Cor F) as the tstat.</p>
PowerUp On/Off	<p>Power on Mode (0-3, 3)</p> <p>This setting allows the thermostat to power up in one of three modes: 0 = power off, 1 = power up in on mode, 2 = last value (default), 3 = auto mode. The on and off settings are self explanatory and are useful in certain DDC applications where the central controller can cycle the power to each thermostat to sweep the moff each evening for example. The default value is "last value" and will cause the thermostat to power up in whatever state it was in before the power outage.</p>

More Detailed Manual

Description

Code	Description (Range, Default)
AnalogOut1 Setting AnalogOut2 Setting	<p>Output settings (0-4, 0) Sets the full-scale voltage of the analog outputs. Ou1 sets analog out 1 (Cooling). Ou2 sets analog out 2 (Heating). This setting is used to match the analog outputs to various types of actuators, transducers or other controllers. For example, by setting the output range to act over a 5VDC scale you can set the tstat up as a transducer to interface into a master DDC controller. Or perhaps you have a valve that operates over the 2-10VDC range, this 'output' type setting lets you tailor the tstat to the particular application. OuX = 0, the output will act in on/off mode. There are 4 types of tstats. Only the Tstat5A and Tstat5CM have analog output capability. For Tstat5B and Tstat5C, the firmware recognizes the relay and this will be permanently set to 0 and is not adjustable. For Tstat5A and Tstat5CM with analog outputs, the output will be 0V when OFF and 10V when ON. This is useful only if you happen to have a Tstat5A or 5CM and need a couple of extra on/off outputs. OuX = 1, the outputs will modulate from 0V to 10V over the 0-100% range of any particular stage of heating or cooling. OuX = 2, same as the '1' setting but the output modulates over the 0-5V scale OuX = 3, same as the '1' setting but the output modulates over the 2-10V full scale OuX = 4, same as the '1' setting but the output modulates in reverse i.e. 10V-0V Note: For a 4-20ma actuator it is simple to convert the 2-10VDC signal to a 4-20ma signal by tying in a 250 ohm resistor in series with the output and making sure the grounds of the actuator and tstat are common.</p>
Max Setpoint Min Setpoint	<p>Setpoint Minimum (0-255, 15) for deg C, (0-255, 55) for deg F Setpoint Maximum (0-255, 50) for deg C, (0-255, 99) for deg F Rev24: The maximum and minimum allowable user setpoint settings. The occupants cannot adjust the setpoint above or below these settings. The min and max setpoint values are in increments of 1° (i.e. 20 means 20°) and are in the same units (C or F) as the tstat. Note: the heating and cooling deadbands act in a way that reduces these settings by the amount of the deadband. For example, if the highest setpoint allowed is 'SHI' = 30°C and the heating deadband 'Hdb' = 2°C, heating will actually only be active up to 28°C. Similarly, if the 'Cdb' cooling deadband parameter is at 2°C and the minimum setpoint is at 20°C, then cooling takes place only as low as 22°C.</p>
MenuLock mode	<p>Keypad lockout (0-3, 0) Rev25 only: This setting is useful to keep the building occupants from experimenting in the menu system. When the LOC parameter is set to '1' the keypad will be locked out from all menu operations. The normal operation of the keypad is not affected; the fan and setpoint buttons work as usual. When the LOC parameter is set to '2' the keypad will be locked out from partial menu operations allowing maintenance personnel to access some of the less critical menu parameters while maintaining a LOC on functions reserved for the primary administrator. This option allows access to calibration of the internal and external temperature sensor (CAL and CAE) and the override time parameter (ORT). LOC = 3, The user can not do anything from keypad except enter menu mode. In menu mode, the user can set setpoint, fan speed, calibration and override timer. When the menu system is locked out, the only way to adjust the tstat parameters is through the network port or through the communications jack at the bottom of the tstat. The parameter can be set back to '0' only through the communications ports as well.</p>
Valve Travl Time	<p>Valve Transient Time (10-255, 0) This setting allows the user to adjust the valve transient time from fully open to fully closed. Value ranges from 10 (10s) to 255 (255s)</p>
RS485/ZGB Select	<p>Select RS485 or ZIGBEE communication mode</p>
MODBUS BACNET	<p>Switch modbus protocol or bacnet protocol</p>
WIFI Mode	<p>Select ADHOC mode or Infra mode network. This only for Tstat wifi product</p>
Factory Default	<p>Factory Default Setting (0-1, 0) This allows the user to get the factory default setting back</p>

Modbus Register List

Tstat8	Count	Register and Description
0 to 3		Serial Number - 4 byte value. Read-only
4 to 5		Software Version– 2 byte value. Read-only
6		ADDRESS. Modbus device address
7		Product Model. This is a read-only register that is used by the microcontroller to determine the product
8		“Hardware Revision. This is a read-only register that is used by the microcontroller to determine the hardware rev”
9		PIC firmware version
10		PIC version of Humidity module
11		“PLUG_N_PLAY_ADDRESS, ‘plug n play’ address, used by the network master to resolve address conflicts. See VC code for algorithms”
14		Spare
15		Bau - Baudrate, 0=9.6kbaud, 1=19.2kbaud 2=38.4kbaud 3=57.6kbaud 4=115.2kbaud 5=76.8kbaud 6=1.2kbaud 1=4.8kbaud 1=14.4kbaud
16		Firmware Update Register, used to show the status of firmware updates. Writing 143 sets the config back to out of the box except for Modbus ID and baud rate. Write 159 to fix the current config as the user defaults, this is done automatically by T3000 any time a config file is loaded. Writing 175 resets the unit back to the user defaults.
17~19		Spare
20		Hardware Options Register, starting with LSB: Bit0=Clock present or not, Bit1 = Humidity present or not, Bit2 = CO2 Sensor, Bit3=CO sensor, Bit4 = Motion Sensor
21		PANID for zigbee devices
22		Device type of zigbee. 0 means coordinator, 1 means router
23~24		Channel of Zigbee, default channel is channel 13, 0x00002000
25		Zigbee module software revision
26~33		Zigbee extended address(MAC address)
34		Set 1 to reboot zigbee module
35~50		Security key
51		The number of zigbee neighbour around
52		The modbus ID of the 1st zigbee neighbour
53		The signal strength of the 1st zigbee neighbour
54		The modbus ID of the 2nd zigbee neighbour
• • •		

*The register list is very long ,it can be downloaded as an excel spreadsheet (03ModbusBacnetRegisterList.xls) at the following link:<http://tinyurl.com/ybaj9d3u>

Bacnet Register List

Support BACnet Object Type	
analog-input, analog-output, analog-value, binary-input, binary-output, device	
Support BACnet Service	
who-is, i-am	
object-identifier, object-name, object-type, present-value, units, object-list, vendor-id, vendor-name, system-status, confirmed-service, unconfirmed-service	
	BIP Object
Analog-value	AV0:baudrate select
Analog-input	AV0:temperature present value AV1~AV8:AV1~8 present value
Analog-output	AV1:analog output 1 value AV2:analog output 2 value
Binary-output	BO1~5:Relay Output1~5
Device	device-identifier,device-name